

HomingGame

www.gametube.hk

Email:hominggame224@gmail.com

Whatsapp:0086-18688409495

FUSION4 MANUAL 五合一說明書



1. THE GREAT TRAIN-ROBBERY 火車



2. RED HOT BUFFALO 公牛



3. PIGGY'S BIG BREAK 豬






5.PLUNDERIN' PIRATES 海盜




A. Connection Machine Introduction

- I. This machine is support 2~50 machine connection. It needs to buy a main board, which support the animate on the big screen.
- II. The main board(server) is connecting to the hub by network line; other boards use network line to link to hub.
- III. It can not only change the setting of all machines on main board, but also change the setting on every single machine.
- IV. It can check total accounting and every single machine's accounting on the main board.



B. System Setting

Push 【Setting Button(A20)】 will get into setting menu.




- I. CONFIGURE TERMINAL: SYSTEM SETUP, SET TIME, MACHINE ID, or PASSWORD
- II. CONFIGURE GAME: SET GAME ACTIVE, BET, JACKPOT, or VOLUMN
- III. CONFIGURE DEVICES: BILL ACCEPTOR SETUP
- IV. SCREENSHOT VIEWER: TO SEE THE SCREENSHOTS
- V. REPORTS: TOTAL or PERIOD ACCOUNTS, IN-OUT RECORD, DECODE, SYSTEM LOG
- VI. GAME SELECTION: EXIT SYSTEM SETTING MENU

I. CONFIGURE TERMINAL



- i. **SYSTEM SETUP** : It can adjust every function in this machine.



System Setup Introduction

Project	Setting Option	Default
COIN RATE	\$0.01, \$0.02, \$0.05, \$0.10, \$0.20, \$0.50, \$1.00, \$2.00, \$5.00, \$10.00, \$20.00, \$50.00, \$100.00, \$200.00, \$500.00, \$1000.00, \$2000.00, \$5000.00, \$10000.00	\$1.00
TICKET RATE	\$0.01, \$0.02, \$0.05, \$0.10, \$0.20, \$0.50, \$1.00, \$2.00, \$5.00, \$10.00, \$20.00, \$50.00, \$100.00, \$200.00, \$500.00, \$1000.00, \$2000.00, \$5000.00, \$10000.00	\$1.00
KEY IN RATE	\$0.01, \$0.02, \$0.05, \$0.10, \$0.20, \$0.50, \$1.00, \$2.00, \$5.00, \$10.00, \$20.00, \$50.00, \$100.00, \$200.00, \$500.00, \$1000.00, \$2000.00, \$5000.00, \$10000.00	\$100.00
KEY OUT RATE	\$0.01, \$0.02, \$0.05, \$0.10, \$0.20, \$0.50, \$1.00, \$2.00, \$5.00, \$10.00, \$20.00, \$50.00, \$100.00, \$200.00, \$500.00, \$1000.00, \$2000.00, \$5000.00, \$10000.00	\$100.00
BILL RATE	\$0.01, \$0.02, \$0.05, \$0.10, \$0.20, \$0.50, \$1.00, \$2.00, \$5.00, \$10.00, \$20.00, \$50.00, \$100.00, \$200.00, \$500.00, \$1000.00, \$2000.00, \$5000.00, \$10000.00	\$1.00
IN LIMIT	\$100.00, \$200.00, \$500.00, \$800.00, \$1000.00, \$2000.00, \$5000.00, \$8000.00	\$5000.00
CREDIT LIMIT	\$10000.00, \$20000.00, \$30000.00, \$50000.00, \$80000.00, \$100000.00	\$10000.00
COLLECT TYPE	COIN, TICKET, PRINTER	COIN
WIN A SPIN	ON, OFF	ON
NUDGE TIMER	OFF, 15 seconds, 20 seconds, 25 seconds, 30 seconds	30 seconds
CHOOSE REELS	ON, OFF	ON
USE REEL COVERS	ON, OFF	OFF
CHOICE ON LOSS	ON, OFF	OFF
DISPLAY	CREDIT, MONEY	MONEY
SCREEN ORIENTATION	NORMAL, REVERSE	NORMAL
PAYOUT RATE	85.00%-99.50%	98.00%
PLACE TYPE	MINI, MIDDLE LARGE	MINI

MACHINE TYPE	STANDALONE, LINK	STANDALONE
--------------	------------------	------------

- ii. SET DATE / TIME
- iii. RESTORE
- iv. SET MACHINE ID
- v. CHANGE PASSWORD

Please input new passwords:

1	2	3	
4	5	6	
7	8	9	
Cancel	0	←	


< Admin RETURN Games >

✧ **Default: 8888**

II. CONFIGURE GAME



i. GAMES ACTIVE:



ii. SET BET

\$0.25	<input type="button" value="ON"/>	\$2.50	<input type="button" value="ON"/>
\$0.50	<input type="button" value="ON"/>	\$3.00	<input type="button" value="ON"/>
\$0.75	<input type="button" value="ON"/>	\$4.00	<input type="button" value="ON"/>
\$1.00	<input type="button" value="ON"/>	\$5.00	<input type="button" value="ON"/>
\$1.50	<input type="button" value="ON"/>	\$10.00	<input type="button" value="ON"/>
\$2.00	<input type="button" value="ON"/>	\$20.00	<input type="button" value="ON"/>

< Admin

RETURN

SAVE

Games >

iii. SET JACKPOT

GRAND PRIZE BASE\$1000.00

MAJOR PRIZE BASE\$100.00

MINOR PRIZE BASE\$10.00

GRAND PRIZE CONT %0.8%

MAJOR PRIZE CONT %1.2%

MINOR PRIZE CONT %1.6%

MIN ELIGIBLE BET\$1.00

< Admin


RETURN

SAVE


Games >

PROJECT	SETTING OPTION	DEFAULT
GRAND PRIZE BASE	\$1000, \$1500, \$2000,...\$10000, \$15000, \$20000,..., \$100000	\$5000.00
MAJOR PRIZE BASE	\$50,\$60..., \$100,\$150,\$200,...,\$950, \$1000 \$1500....\$9500,\$10000	\$1000.00
MINOR PRIZE BASE	\$10, \$20, ... \$100,\$150,\$200....\$1000	\$100.00
GRAND PRIZE CONT %	0.1%, 0.2%,...,2.4%, 2.5%	0.8%
MAJOR PRIZE CONT %	0.1%, 0.2%,...,2.4%, 2.5%	1.2%
MINOR PRIZE CONT %	0.1%, 0.2%,...,2.4%, 2.5%	1.6%
MINI ELIGIBLE BET	\$1.00, \$.1.50,..., \$3.00, \$4.00, \$5.00, \$10.00, \$20.00	\$1.00

iv. VOLUMN



III. CONFIGURE DEVICES



IV. SCREENSHOT VIEWER



V. REPORTS

COIN IN	\$0.00	COIN OUT	\$0.00
KEY IN	\$0.00	KEY OUT	\$0.00
BILL IN	\$0.00	TICKET	\$0.00
TOTAL IN	\$0.00	WIN	\$0.00
TOTAL OUT	\$0.00	PERCENT	0.00%
GRAND JP COUNT	0	GRAND JP WIN	\$0.00
MAJOR JP COUNT	0	MAJOR JP WIN	\$0.00
MINOR JP COUNT	0	MINOR JP WIN	\$0.00

Game	Games	Avg Play	Total Play	Total Win	Net	Paymet%
King Kongs	0	\$0.00	\$0.00	\$0.00	\$0.00	0.00%
Plandoria Pirates	0	\$0.00	\$0.00	\$0.00	\$0.00	0.00%
Red hot buffalo	0	\$0.00	\$0.00	\$0.00	\$0.00	0.00%
The Great Train Robbery	0	\$0.00	\$0.00	\$0.00	\$0.00	0.00%
Piggy's Big Break	0	\$0.00	\$0.00	\$0.00	\$0.00	0.00%
Jackpot				\$0.00		
Totals	0	\$0.00	\$0.00	\$0.00	\$0.00	0.00%

	Current record 2020/11/13 10:33:08	Last record 1970/01/01 08:00:00
ALL IN	\$0.00	\$0.00
ALL OUT	\$0.00	\$0.00
PERCENT	0.00%	0.00%
ALL PLAY IN	\$0.00	\$0.00
ALL PLAY OUT	\$0.00	\$0.00
PERCENT	0.00%	0.00%
PLAY COUNT	0	0
WIN COUNT	0	0
PERCENT	0.00%	0.00%


V2.1.2

Total Profit	0
Current Profit	0
Machine Number	20660801
Decode Count	0
Rand Number	80242053

0 0 0 0 0 0 0 0

VI. GAME SELECTION

C. Main Board



Bill acceptor: ICT, ITL, JCM, MEI (RS232)

Printer: GP58 (Pulse)

Touch Panel: 3M compatible(RS232) or USB infrared touch panel

Button:



D. Connector Diagram

36 PIN Connector Diagram

Component Side		Solder Side
	1	
Left Speaker (+)	2	Left Speaker (-)
Right Speaker (+)	3	Right Speaker (-)
GAME1 / EXIT	4	
GAME2 / SPIN SW/SELECT A/ LOWER A	5	
GAME3 /←/SELECT B/LOWER B	6	
GAME4 /→/SELECT C/ LOWER C	7	
	8	
PLAY BUTTON	9	
GAME5 / AUTO PLAY	10	Error Lamp
BET- / RAISE B	11	
BET+ / RAISE C	12	Service Lamp
HELP / RAISE A	13	
	14	
	15	Service Button
	16	
Bill Acceptor	17	
Coin in SW	18	Key In Button
Door SW	19	Ticket Out SW
Setting Button	20	Check Button
Pay Out SW	21	Key Out SW
	22	Coin Out SW
	23	
Meter In	24	
Meter Out	25	
	26	Ticket Out SSR
	27	
	28	Lamp: Big Win
Lamp: Play Button	29	Lamp: GAME1 / EXIT
Lamp: GAME5 / AUTO PLAY	30	Lamp: GAME2 / SPIN SW/ SELECT A/ LOWER A
Lamp: BET- / RAISE B	31	Lamp: GAME3 /←/SELECT B/ LOWER B
Lamp: BET+ / RAISE C	32	Lamp: GAME4 /→/SELECT C/ LOWER C
Lamp: HELP / RAISE A	33	
	34	Lamp: Pay Out
NC	35	NC

GND	36	GND
-----	----	-----

10 PIN Connector Diagram

Component Side		Solder Side
GND	1	GND
GND	2	GND
+5V	3	+5V
+5V	4	+5V
+12V	5	+12V
	6	
Hopper SSR	7	
	8	
GND	9	GND
GND	10	GND

✧ You can use touch screen or mouse to setting system. If you don't have touch screen, please insert the mouse before turn on the power.